

## Chapter 10. Viewing, Reporting and Ground Truthing the Results

### 10.1 Guidance for Reporting Loss Results

There is no single format that is appropriate for presentation of loss study results. The format will depend on the use of the results and the intended audience. The audience can vary from the general public to technical experts. Decision-makers such as city council members and other government officials may require only summaries of losses for a region. Emergency response planners may want to see the geographical distribution of all losses and damage for several different earthquake scenarios. **HAZUS** provides a great deal of flexibility in presenting results. Results can be presented in a tabular or map form; which maps or tables are selected for reports will depend on the application. In any case, the users of the results should be involved from the beginning in determining the types and formats of the results that best suit their needs.

In previous loss studies, authors of reports have had the difficult task of trying to combine the study results with the theory of how they were calculated. Consequently, reports often seemed overly technical, reducing their readability and usefulness for many audiences. The users of **HAZUS** can refer to the *Technical Manual*, which describes all of the theories and equations that provide the basis of any loss estimate. Therefore, reports do not need to, *and probably should not*, include technical discussions of theory. Instead, reports should focus on describing results in non-technical language that is easily understood by the intended audience.

While no particular format for presenting results can be recommended, several general statements about reporting of results can be made. Reports should serve to clarify the meaning of the loss estimates. As an example, the reporting of economic loss should indicate whether both direct and indirect losses are included in the estimates. The report should indicate whether losses are due only to structural and non-structural damage or if they should also include monetary losses resulting from loss of function. Casualty reports should indicate that casualties include only those that result from building damage and bridge collapse and do not include injuries and deaths from fires, flood, releases of hazardous materials or medical causes such as heart attacks. It should be clarified that in most cases losses are not calculated for specific buildings or facilities, but instead are based on the performances of entire classes of buildings and lifelines. These are just a few examples of the types of clarifications that should appear in reports.

Reports should also clarify for the reader what assumptions were made in developing the scenario and inventory and in calculating losses. For example, were losses based on default inventories or were default inventories augmented? Were default repair costs and repair times used? If not, what values were used? Were soils maps provided or were results based on a default soil type? What assumptions were made in selecting the scenario earthquake? Is it based on an historical event? Is it based on a specified probability of occurrence (e.g. 10% chance in 200 years)? What types of assumptions were made about design and construction quality?

A criticism of past studies is that there has been little qualitative or quantitative treatment of uncertainty. Discussions with users of previous studies have indicated that users need information about where errors in prediction are most likely to occur. While this methodology does not explicitly include a technique for carrying the uncertainty of each variable through the entire calculation from PESH input to loss estimates, sensitivity analyses are useful for providing bounds on loss estimates (see Section 9.8). At a minimum, reports should make some statement about the uncertainty of the input values.

## 10.2 Module Outputs

Each of the modules of **HAZUS** provides the user with a series of outputs. The outputs can be in a numerical or graphical form. Some of the modules yield intermediate results that are used as inputs to other modules. For example, the PESH module determines ground motion at different locations for a specified earthquake scenario. This information by itself may not be very useful for hazard mitigation and emergency planning. However, the results of the PESH module are used as an input to determine the damage to structures in the Direct Physical Damage module. In the following sections, summaries of the outputs of the modules are provided.

## 10.3 Potential Earth Science Hazards

**HAZUS** provides information about the expected ground shaking response for a specified event in the given study region. The user may specify a deterministic scenario event. For the purposes of emergency response and preparedness, a scenario event is commonly used to estimate earthquake consequences and losses. The user can also opt for a pseudo-probabilistic approach that can be used to compute expected annual losses. This type of approach may be useful for comparing mitigation strategies. Finally the user can use an existing ground motion map prepared by an expert.

Table 10.1 summarizes the module outputs for these three options. In all three cases, the user is provided with ground shaking in the study region characterized in terms of peak ground acceleration (PGA) and spectral accelerations (5% damping) at two specific structural periods (0.3 and 1.0 seconds).

**Table 10.1 PESH Module Outputs - Ground Motion/Site Effects**

<b>Component</b>	<b>Description of Output</b>	<b>Measure</b>
Deterministic Event	<b>HAZUS</b> determines census tract ground motion and develops region-wide ground motion contour maps based on a user-defined scenario event.	a) Census Tract Ground Shaking b) PGA Contour Maps c) Spectral Contour Maps
USGS Probabilistic Seismic Hazard Maps	<b>HAZUS</b> includes spectral contour maps at two seismic hazard levels: 2% probability of exceedance in 50 years and 10% probability of exceedance in 50 years	a) PGA Contour Maps b) Spectral Contour Maps
User-Supplied Ground Shaking Maps	The user supplies region-wide ground motion contour maps which are used as the ground motion inputs to <b>HAZUS</b>	a) Census Tract Ground Shaking b) PGA Contour Maps c) Spectral Contour Maps


For identified susceptible areas, **HAZUS** provides information concerning the probability of an expected level of permanent ground deformations (PGD) due to the specified scenario event. In this methodology, permanent ground deformation is defined as liquefaction, landsliding and surface fault rupture. PGD are important in estimating losses to and functionality of lifelines. Table 10.2 summarizes the ground deformation outputs of the PESH module. PGD are reported in terms of contour maps of ground deformations (in meters) or site specific PGD.

**Table 10.2 PESH Module Outputs - Ground Deformation**

<b>Component</b>	<b>Description of Output</b>	<b>Measure</b>
Liquefaction	<b>HAZUS</b> determines the probability of and expected level of permanent ground deformations for liquefaction susceptible sites during the deterministic, probabilistic, or user-defined event.	a) PGD Contour Maps b) Location-Specific PGD
Landsliding	<b>HAZUS</b> determines the probability of and expected level of permanent ground deformations for landsliding susceptible sites during the deterministic, probabilistic, or user-defined event.	a) PGD Contour Maps b) Location-Specific PGD
Surface Fault Rupture	<b>HAZUS</b> determines the probability of and expected level of permanent ground deformations for surface fault rupture susceptible sites during the deterministic, probabilistic, or user-defined event.	a) PGD Contour Maps b) Location-Specific PGD

Outputs of the PESH module can be accessed from the **Results|Ground Motion** menu (See Figure 10.1). Ground motion maps can be viewed in two forms: census tract-based or contour maps. Census tract-based maps are generated by evaluating the ground motion at the center of the census tract and then assigning that value of ground motion to the

census tract. The census tract based information is used to derive the damage and loss estimates for the general building stock. Contour maps that are generated by **HAZUS** are for display purposes only. Contour maps that are digitized and entered by the user can be used for further computations. From the **Ground Motion or Failure** menu, you can plot a variety of maps by choosing one of the options: **Ground Motion (By Census Tracts)** or **Contours or Ground Failure Maps** (see Figure 10.1). For the **Ground Motion (By Census Tracts)** option, as shown in Figure 10.2, you can generate acceleration, displacement, velocity, PGV or PGA maps by clicking on the appropriate column of data and then clicking on the **Map** button. Examples of these maps are found in Figures 10.3 and 10.4. For the **Contours or Ground Failure Maps** option, you may plot any of the parameters shown in Figure 10.5 provided that you have already run the specific analysis that you want to plot. Click on your choice in Figure 10.5, followed by the **Map** button.



**Figure 10.1 Accessing PESH module results**

**Ground Motion Results**

Acceleration | Displacement | Velocity, PGV and PGA

Table: Spectral acceleration

	Tract	At 0.3 sec (g)	At 1.0 sec (g)
1	41005020100	0.8550	0.4728
2	41005020200	0.6906	0.2559
3	41005020301	0.6906	0.2559
4	41005020302	0.8559	0.4743
5	41005020401	0.8421	0.4526
6	41005020402	0.6906	0.2559
7	41005020501	0.6906	0.2559
8	41005020502	0.6906	0.2559
9	41005020600	0.6906	0.2559
10	41005020700	0.8589	0.4789
11	41005020800	0.7717	0.3853
12	41005020900	0.7316	0.3619
13	41005021000	0.8553	0.5336
14	41005021100	0.7379	0.3654
15	41005021200	0.6136	0.2048
16	41005021300	0.7384	0.3517
17	41005021400	0.5825	0.1908
18	41005021500	0.7397	0.3664
19	41005021601	0.5838	0.2475

Close Map Print..

Figure 10.2 Selecting site specific data generated in the PESH module




Figure 10.3 Map of 0.3 second spectral acceleration by census tract




Figure 10.4 Map of peak ground acceleration by census tract




Figure 10.5 Window to select PESH contours for mapping

### 10.3.1 Ground Motion Descriptions

Many of the earlier regional loss estimation studies and methods have based losses on MMI and isoseismal maps (maps showing areas of constant MMI). In **HAZUS**, PGA, PGV and SA characterize ground shaking. The use of spectral acceleration allows **HAZUS** to account for possible amplification of building motion and consequently damage due to sympathetic response of a building to the earthquake motions. Sympathetic response of a building (or amplification of building shaking) is similar to

what you experience when on a swing. If you pump your legs at a certain frequency, the swing will go very high and very fast. If the ground motion shakes the building at a certain frequency the building will experience amplification of its motions. Fast shaking excites short buildings and slower shaking excites tall buildings. Presenting ground motion in terms of spectral velocity and spectral acceleration gives information about the frequency of the ground shaking. This in turn can be used to determine which buildings (tall or short) are most excited and thus most damaged by a particular earthquake.

#### 10.4 Direct Physical Damage - General Building Stock

The direct physical damage module of HAZUS provides information about the level of damage to the study region's general building stock. Damage to the general building stock is not evaluated on a building-by-building basis. Instead, damage is estimated and reported for groups of buildings in each census tract. Damage to the general building stock is defined in terms of the probability that a specific model building type will reach or exceed a specified level of damage when subjected to a given level of ground motion. Damage estimates are then converted in other modules into monetary losses and social losses such as casualties and shelter demands (see, for example, Figure 10.6).

Losses such as the costs of reconstruction, the length of business interruption, the number of people needing shelter and the severity of injuries and number of casualties all depend on the severity of the damage. While estimation of social and economic losses is the ultimate goal of a loss study, some knowledge of the geographical distribution of damage may be helpful in planning for post-earthquake response or in determining strategies for mitigation. For example, if the scenario identifies a particular area where a large number of buildings are likely to collapse, planning for rescue efforts in this area may be important.




Figure 10.6 Losses calculated from damage estimates

Damage is described by five damage states (none, slight, moderate, extensive and complete) that are defined in detail in Section 9.4.2. Estimates of earthquake damage are provided in terms of damage state probabilities or building count. For a specified earthquake, the user is provided with the probability of a structural type experiencing a certain level of damage. For example, for a given earthquake, wood frame structures

may have a probability of 0.9 of experiencing no damage and a probability of 0.1 of experiencing slight damage. As shown in Table 10.3, damage state probabilities are provided for structural as well as non-structural damage, where as building counts are only provided for structural damage. To provide the most flexibility to the user, the module delivers damage state probabilities for model building types, specific occupancy classes and general occupancy classes. Results are available in a tabular or map format.


**Table 10.3 Direct Physical Damage Module Outputs - General Building Stock**

<b>Component</b>	<b>Description of Output</b>	<b>Measure</b>
Model Building Type	<b>HAZUS</b> determines the damage state probability for each model building type (36) by census tract in the study region. Results are presented for each design level and construction quality bias. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Structural Damage State Building Counts
General Building Type	<b>HAZUS</b> determines the damage state probability for each general building type (7) by census tract in the study region. Results are presented for each design level and construction quality bias. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Structural Damage State Building Counts
Specific Occupancy Class	<b>HAZUS</b> determines the damage state probability for each specific occupancy (28) by census tract in the study region. Results are presented for each construction quality bias. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Structural Damage State Occupancy Counts
General Occupancy Class	<b>HAZUS</b> determines the damage state probability for each general occupancy (6) by census tract in the study region. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Structural Damage State Occupancy Counts

Using the Results|General Building Stock menu can access output of the damage module. Results are provided in a tabular format (see Figures 10.7 and 10.8) or in a map form (Figures 10.9 through 10.11). In both cases the following information can be displayed:

- Probability of none, slight, moderate, extensive or complete structural damage, acceleration sensitive non- structural damage or drift sensitive non- structural damage.
- Probability of at least slight, at least moderate, at least extensive for structural or either type of non-structural damage.

To thematically map a given value, select its column by clicking on the header, and then clicking **Map**. Click on **Return** to go back to the dialog that displays tabular results.



**Figure 10.7** Damage state probabilities by general occupancy




Figure 10.8 Damage state probabilities by general building type






Figure 10.9 Map of probability of slight structural damage for commercial occupancy



**Figure 10.10 Map of moderate structural damage for retail trade**



**Figure 10.11 Map of moderate non-structural drift sensitive damage for retail trade**

### 10.5 Direct Physical Damage - Essential Facilities

**HAZUS** provides information about the damage state probability of the study region's essential facilities. In contrast to the general building stock, where damage probabilities are calculated for groups of buildings, for essential facilities the damage probabilities are estimated for each individual facility. As with the general building stock, the damage states are none, slight, moderate, extensive and complete. Both structural and non-structural damage is considered. As can be seen in Table 10.4, damage state probabilities are estimated for health care facilities, police and fire stations, emergency operation centers and schools. In addition, loss of beds and facility functionality is computed as a function of time for health care facilities.

Output of the essential facilities damage module can be obtained by using the **Results|Essential Facilities** menu. As with the general building stock, results are provided in a tabular format or in a map form. An example of the functionality of health care facilities is found in Figure 10.12. To thematically map a given value, select its column by clicking on the header, and then clicking **Map**. Click on **Return|Return to Table** to go back to the dialog that displays tabular results.

**Table 10.4 Direct Physical Damage Module Outputs - Essential Facilities**

Facility Type	Description of Output	Measure
Health Care Facilities	<b>HAZUS</b> determines the damage state probabilities for each health care facility in the study region. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements. The expected reduction in available beds for each facility is also determined.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Loss of Beds and Facility Functionality
Police/Fire Stations Emergency Operations Centers Schools	<b>HAZUS</b> determines the damage state probabilities for each facility in the study region. Damage state probabilities are determined for i) structural elements, ii) non-structural drift-sensitive elements, and iii) non-structural acceleration-sensitive elements.	a) Structural Damage State Probabilities b) Non-structural Damage State Probabilities c) Functionality @ Day 1

The screenshot shows a software window titled "Essential Facilities Analysis Results". It has three tabs: "Medical Care", "Emergency Response", and "Schools". The "Medical Care" tab is selected. Below the tabs, there is a "Table type:" dropdown menu set to "Functionality". Below that is a "Table:" label and a table with the following data:

	ID	Class	@ Day 0	# Beds D0	@ Day 1	# Beds D1	@ Day 3	# Beds D3	@
1	1	EFHM	22.00	28	23.04	29	29.20	36	
10	10	EFHL	58.00	300	59.04	306	65.19	338	
11	11	EFHM	79.00	97	79.62	98	83.24	102	
12	12	EFHM	34.00	26	35.14	27	41.84	32	
13	13	EFHS	45.00	22	46.14	22	52.84	25	
14	14	EFHL	29.00	48	30.14	50	36.85	62	
15	15	EFHS	66.00	22	66.90	23	72.20	25	
16	16	EFHL	26.00	141	27.14	147	33.85	183	
17	17	EFHM	41.00	39	42.19	40	49.17	47	
18	18	EFHL	32.00	118	33.14	123	39.84	147	
19	19	EFHL	57.00	190	58.04	193	64.19	214	
2	2	EFHL	59.00	194	60.00	197	65.86	216	
20	20	EFHL	23.00	37	24.09	39	30.52	49	
21	21	EFHM	23.00	13	24.04	13	30.20	17	
22	22	EFHM	69.00	75	69.85	75	74.88	81	
23	23	EFHM	4.00	3	4.38	3	6.63	4	

At the bottom of the window are three buttons: "Close", "Map", and "Print..".

Figure 10.12 Functionality of health care facilities

## 10.6 High Potential Loss Facilities

High potential loss facilities tend to be unique and complex facilities that would require in-depth evaluation by structural and geotechnical engineers to assess their vulnerability to earthquakes. These types of facilities are often designed to codes and standards that exceed those for general building stock. Thus, the vulnerability curves that are used for general building stock may be inappropriate for high potential loss facilities. It is likely that the user/engineer will need to define vulnerability curves that are specific to these facilities. Furthermore, often the owners of these facilities have already performed in-depth, site-specific seismic hazard analyses. For these reasons, **HAZUS** is limited to providing information concerning the location of the study region's high potential loss facilities (see Table 10.5). This can serve as a first step in developing mitigation and preparedness efforts. You may opt to perform a vulnerability analysis of a specific facility, and include the results of the special study with the results of the methodology. Locations of and details about high potential loss facilities are found in the **Inventory|High Potential Loss Facilities|Inventory Data** menu. Results for military facilities are obtained through the **Results|Military Installations** menu.



- Moderate damage            20% chance
- Extensive damage         44% chance
- Complete damage         24% chance

Based upon this estimate of damage, the expected functionality of the bridge would be

- 14% functional after one day;
- 26% functional after 3-days;
- 34% functional after 7 days;
- 39% functional after 30 days;
- 60% functional after a 3-month restoration period.

Another interpretation of these results is that after one day, 14% of the bridges of this type would be functional and after 3 months, 60% of these bridges would be functional. Interdependency of the components on overall transportation system functionality is not addressed by the methodology. Lifelines are divided into transportation systems and utility systems. Table 10.6 summarizes the outputs for each of the seven transportation lifeline systems.

**Table 10.6 Direct Physical Damage Module Outputs - Transportation Systems**

System	Description of Output	Measure
Highway System Railway System Light Rail Bus Ferry Port Airport	a) <b>HAZUS</b> determines the damage state probability for each transportation system component in the study region.	a) Component Damage State Probabilities
	b) <b>HAZUS</b> determines the probability of functionality for each transportation system component at discrete time intervals.	b) Component Probability of Functionality

Table 10.7 summarizes the outputs of **HAZUS** for the study region's utility system components. A simplified system analysis is performed for potable water systems and electric power systems. These analyses make simplified assumptions about the serviceability of the systems based on the number of pipe leaks and breaks or the functionality of medium voltage substations.

**Table 10.7 Direct Physical Damage Module Outputs - Utility Systems**

<b>System</b>	<b>Description of Output</b>	<b>Measure</b>
Potable Water	a) <b>HAZUS</b> determines the damage state probabilities for each potable water component in the study region. b) <b>HAZUS</b> determines the probability of functionality for each potable water component at discrete time intervals. c) <b>HAZUS</b> supports simplified potable water system analysis for the study region.	a) Component Damage State Probabilities b) Component Probability of Functionality c) # of Households without water
Waste Water Natural Gas Crude and Refined Oil Pipeline Communication	a) <b>HAZUS</b> determines the damage state probabilities for each system component in the study region. b) <b>HAZUS</b> determines the probability of functionality for each system component at discrete time intervals.	a) Component Damage State Probabilities b) Component Probability of Functionality
Electric Power	a) <b>HAZUS</b> determines the damage state probabilities for each electric power component in the study region. b) <b>HAZUS</b> determines the probability of functionality for each electric power component at discrete time intervals. c) <b>HAZUS</b> supports simplified system analysis for the study region.	a) Component Damage State Probabilities b) Component Probability of Functionality c) # of Households without power

Output of the lifeline module can be viewed in terms of damage states or in terms of functionality and can be displayed in a tabular or map format. Figure 10.13 shows a table of the damage to airport facilities for the study region. For each of the airports in the study region (identified by ID number), the probability of being in one of the five damage states is tabulated. For airport facility number 1, the probability of no damage is 0.22, slight damage is 0.34, and moderate damage is 0.32. This information can be mapped, as shown in Figure 10.14, by clicking on the **Map** button. Each airport facility is identified by a symbol. The shape or color of the symbol is associated with a range of probabilities. For example, if the symbol is square, the probability of slight damage is between 0.32 and 0.34. Users familiar with MapInfo have the option of zooming in on any area and viewing that area more closely as shown in Figure 10.15.

**Transportation Systems Analysis Results**

Highway | Railway | Light Rail | Bus | Port | Ferry | **Airport**


Table type: Facilities Damage States

Table:


ID	Class	None	Slight	Moderate	Extensive	Complete	At Least Slight
1	ATB1M	0.22	0.34	0.32	0.09	0.03	0.78
2	ATB1M	0.10	0.27	0.39	0.17	0.07	0.90
3	ATB1M	0.19	0.34	0.34	0.10	0.03	0.81
4	ATB1M	0.16	0.31	0.36	0.13	0.04	0.84
5	ATB1M	0.10	0.27	0.39	0.17	0.07	0.90
6	ATB1M	0.17	0.32	0.35	0.12	0.04	0.83
7	ATB1M	0.18	0.33	0.34	0.11	0.03	0.82
8	ATB1M	0.14	0.29	0.35	0.16	0.06	0.86
9	ATB1M	0.16	0.32	0.36	0.12	0.04	0.84
10	ATB1M	0.13	0.30	0.37	0.14	0.05	0.87
11	ATB1M	0.16	0.30	0.34	0.15	0.05	0.84
12	ATB1M	0.20	0.34	0.34	0.10	0.03	0.80
13	ATB1M	0.19	0.32	0.32	0.14	0.04	0.81
14	ATB1M	0.24	0.35	0.31	0.08	0.02	0.76
15	ATB1M	0.23	0.35	0.31	0.08	0.02	0.77
16	ATB1M	0.30	0.36	0.27	0.06	0.01	0.70

Close Map Print...

**Figure 10.13 Output of the lifeline module: damage to airport facilities**



**Figure 10.14 Output of the lifeline module: map of probability of slight damage to airport facilities for entire study region**



**Figure 10.15 Map of probability of slight damage to airport facilities for a portion of the study region**

Figure 10.16 shows a table of the functionality of airport facilities at specified periods after the occurrence of the scenario earthquake. According to this table, facility number 1 would be functional with a 63% probability immediately after the earthquake, and functional with a 96% probability after 90 days. Functionality can be mapped, as shown in Figure 10.17, by clicking on the **Map** button. Facilities are mapped as “operational” or “non-operational”. The user must specify a “confidence level” above which the facility is considered operational. In Figure 10.18 the “confidence level” is chosen to be 75%, indicating that if the probability of functionality is greater than 75%, the facility will be considered operational. Based on this definition of operational, the model predicts that many of the airport terminals near the epicenter will be non-operational one day after the event.

**Transportation Systems Analysis Results**

Highway | Railway | Light Rail | Bus | Port | Ferry | **Airport**


Table type: Facilities Functionality

Table:


	ID	Class	at Day 0	at Day 1	at Day 3	at Day 7	at Day 30	at Day 90
1	1	ATB1M	62.78	69.61	84.89	90.20	91.70	96
2	2	ATB1M	46.45	54.74	73.30	79.87	82.72	91
3	3	ATB1M	60.17	67.32	83.30	88.87	90.56	95
4	4	ATB1M	55.14	62.81	79.98	86.00	88.07	94
5	5	ATB1M	46.67	54.95	73.48	80.05	82.88	91
6	6	ATB1M	56.88	64.39	81.17	87.04	88.98	94
7	7	ATB1M	58.92	66.20	82.51	88.19	89.97	95
8	8	ATB1M	51.85	59.25	75.79	81.67	84.39	92
9	9	ATB1M	55.35	63.06	80.30	86.34	88.36	94
10	10	ATB1M	52.05	59.99	77.76	84.00	86.34	93
11	11	ATB1M	54.39	61.55	77.55	83.23	85.74	93
12	12	ATB1M	60.54	67.70	83.71	89.29	90.91	95
13	13	ATB1M	58.07	64.85	79.99	85.35	87.57	94
14	14	ATB1M	65.82	72.30	86.80	91.82	93.09	96
15	15	ATB1M	64.53	71.19	86.08	91.24	92.59	96
16	16	ATB1M	71.25	76.92	89.63	94.01	94.95	97

Close | Map | Print..

**Figure 10.16 Output of the lifeline module: functionality of airport facilities reported by number of days since the occurrence of the earthquake**



**Figure 10.17 Selection of confidence level**



**Figure 10.18 Output of the lifeline module: map functionality of airport terminal buildings**


### 10.8 Induced Physical Damage

**HAZUS** includes information about earthquake-related flooding to enable users to design programs to reduce the likelihood of dam or levee failure and to prepare to cope with those floods that may occur. Development of inundation maps requires an understanding of the downstream topography and the involvement of an experienced hydrologist. In the case of tsunamis, inundation models are complex and are in many cases still in the development stage; therefore, **HAZUS** does not produce inundation maps. Instead, as a first step in assessing the risk to a study region, all dams and levees are identified. The existing national inventory of dams that is provided with the software includes a hazard classification (low, significant, high) based on the downstream urban development and potential economic loss. The potential for tsunamis and seiches are assessed (by the user outside **HAZUS**) without any estimate of size or consequence. Table 10.8 summarizes the outputs that are available from **HAZUS**.


**Table 10.8 Induced Physical Damage Module Outputs – Inundation**

<b>Component</b>	<b>Description of Output</b>	<b>Measure</b>
Tsunami	<ul style="list-style-type: none"> <li>a) The methodology provides rules to determine if tsunamis are a threat to the study region.</li> <li>b) The user can import existing tsunami inundation maps and overlay with population and economic value maps.</li> </ul>	<ul style="list-style-type: none"> <li>a) Qualify Potential Threat</li> <li>b) Exposed Population Exposed Value (\$)</li> </ul>
Seiche	<ul style="list-style-type: none"> <li>a) The methodology provides rules to determine if seiches are a threat on any body of water in the study region.</li> <li>b) The user can import existing seiche inundation maps and overlay with population and economic value maps.</li> </ul>	<ul style="list-style-type: none"> <li>a) Qualify Potential Threat</li> <li>b) Exposed Population Exposed Value (\$)</li> </ul>
Dam Failure	<ul style="list-style-type: none"> <li>a) <b>HAZUS</b> displays the location of all dams in the study region and (for the default database) ranks the potential impact of the dam failure.</li> <li>b) The user can import existing dam failure inundation maps and overlay with population and economic value maps.</li> </ul>	<ul style="list-style-type: none"> <li>a) List of and Locations of Dams and Quantification of Potential Hazard</li> <li>b) Exposed Population Exposed Value (\$)</li> </ul>
Levee Failure	<ul style="list-style-type: none"> <li>a) <b>HAZUS</b> displays the location of the levees in the study region.</li> <li>b) The user can import existing levee failure inundation maps and overlay with population and economic value maps.</li> </ul>	<ul style="list-style-type: none"> <li>a) List of and Locations of Levees</li> <li>b) Exposed Population Exposed Value (\$)</li> </ul>

For all four inundation types, **HAZUS** has the ability to import existing inundation maps. These can then be overlaid with population density maps or maps of inventory to estimate exposed population and exposed inventory. The output of the inundation module is a display of the inundation maps that were specified in the data window shown in Figure 9.32. An example is shown in Figure 10.19. To access this map, use the **Map|Inundation Maps|Dams** menu. This map can be overlaid with population data to obtain an understanding of the exposed population, as shown in Figure 10.20. Alternatively, you can view a table of population, value and area exposure by census tract using the **Results|Inundation** menu (see Figure 10.21). This output is only available if an inundation map has been specified. Highlighting the appropriate column and clicking on the Map button can map any one of the outputs in Figure 10.21.



**Figure 10.19 Display of inundation potential map**



**Figure 10.20 Population data overlaid with the inundation potential map**

The screenshot shows a software window titled "Inundation Analysis Results" with a tabbed interface. The "Dams" tab is selected. Below the tabs, a table is displayed with the title "Table: Exposed population, value, and area from dams inundation". The table has six columns: "Census Tract", "Population", "Value (thous. \$)", "Residential (thous. sq.ft)", "Commercial (thous. sq.ft)", and "Industrial (t)". The table body is currently empty. At the bottom of the window, there are three buttons: "Close", "Map", and "Print...".

Census Tract	Population	Value (thous. \$)	Residential (thous. sq.ft)	Commercial (thous. sq.ft)	Industrial (t)

**Figure 10.21 Tabulation of exposed population, value and area resulting from inundation map**

Assessment of the consequences of a hazardous materials release requires an understanding of the amounts and types of materials that are released as well as, in some cases, a model of a gaseous plume. A single facility may house many toxic and hazardous materials. Without visiting a facility, assessing the vulnerability of the structure and auditing how materials are stored, it is impossible to give a meaningful estimate of risk. Therefore **HAZUS** limits the analysis to locating facilities with hazardous materials and identifying the types and amounts of materials that are stored. Locations of hazardous materials facilities can be mapped and overlaid with ground motion, population and inventory maps. This can provide a preliminary assessment of consequences, which can then be followed up with detailed site-specific studies. In addition, the hazardous facility database can be sorted in a variety of ways allowing the user to view only certain types of materials, facilities with large amounts, highly vulnerable facilities, etc. Table 10.9 summarizes the information available from the hazardous materials module.

**Table 10.9 Induced Physical Damage Module Outputs - Hazardous Material Release**


Component	Description	Measure
Hazardous Materials Facilities	a) <b>HAZUS</b> provides the location of the hazardous material facilities located in the study region. b) <b>HAZUS</b> provides the types and amounts of hazardous materials stored at each location and the health hazard associated with each chemical. c) The user can overlay a map of hazardous material facilities with ground shaking, population, and economic value maps to interrogate the consequences of release at a particular site.	a) List of and Locations of Facilities Containing Hazardous Materials b) Type/Amount of Material Stored at Each Facility

The output of the hazardous materials module is essentially a listing of the materials and plots of locations of sites as shown in Figures 10.22 and 10.23. This information was retrieved using the **Results|Hazardous Materials** menu and then plotted using the **Map** button at the bottom of Figure 10.22. The information in the small box at the left-hand side of Figure 10.23 was retrieved using the information tool (**i**) in the MapInfo Main menu (see Section 2.6.2). By using the information tool and clicking on any one of the sites, you can access all of the stored data for that site.

The screenshot shows a window titled "Hazardous Materials Inventory" with a table of data. The table has columns for ID, Name, Address, City, Stat, and ZipCode. The data includes various industrial and service facilities in Portland, Oregon.

ID	Name	Address	City	Stat	ZipCode
1	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
2	LAND O'LAKES INC. RIVERGATE	15840 N. SIMMONS RD.	PORTLAND	OR	97203
3	LAND O'LAKES INC. RIVERGATE	15840 N. SIMMONS RD.	PORTLAND	OR	97203
4	LAND O'LAKES INC. RIVERGATE	15840 N. SIMMONS RD.	PORTLAND	OR	97203
5	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
6	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
7	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
8	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
9	OREGON STEEL MILLS INC.	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97203
10	INTERNATIONAL MILL SERVICE	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97283
11	INTERNATIONAL MILL SERVICE	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97283
12	INTERNATIONAL MILL SERVICE	14400 N. RIVERGATE BLVD.	PORTLAND	OR	97283
13	NORTHWEST PIPE & CASING CO.	12005 N. BURGARD	PORTLAND	OR	97203
14	NORTHWEST PIPE & CASING CO.	12005 N. BURGARD	PORTLAND	OR	97203
15	NORTHWEST PIPE & CASING CO.	12005 N. BURGARD	PORTLAND	OR	97203
16	NORTHWEST PIPE & CASING CO.	12005 N. BURGARD	PORTLAND	OR	97203
17	PREMIER EDIBLE OILS CORP.	12005 N. BURGARD RD.	PORTLAND	OR	97203
18	PREMIER EDIBLE OILS CORP.	12005 N. BURGARD RD.	PORTLAND	OR	97203
19	PREMIER EDIBLE OILS CORP.	12005 N. BURGARD RD.	PORTLAND	OR	97203
20	MOBIL PORTLAND LUBE PLANT	9420 N.W. SAINT HELENS RD.	PORTLAND	OR	97231
21	CROWN BEVERAGE BOTTLING INC.	10000 N. LOMBARD ST. B.O. BOY	PORTLAND	OR	97203


**Figure 10.22 Default hazardous material database**



**Figure 10.23 Map of default hazardous materials database**


Another feature of **HAZUS** is that you can query the database and plot specific types of data. In Figure 10.27, all of the sites at which ammonia or chlorine are stored have been identified and are plotted as large triangles. This was done using the **Query** menu.

To create such a map, follow these steps. Plot the hazardous materials database for your region using the **Map** button at the bottom of the window shown in Figure 10.22. Then click on the **Return** menu at the upper left-hand corner of the map. Click on **Return to Table**. Close the table using the **Close** button at the bottom of the window (see Figure 10.22). Click on the **Query>Select...** menu and the window shown in Figure 10.24 will appear. Using the **Assist...** button and the various other pull down menus create a query from the table called **HAZMAT**.




**Figure 10.24** Developing a query to identify sites that store ammonia or chlorine


The results of your query will appear in a table such as the one shown in Figure 10.25. To plot these results, click on the map so that it is the active window, then use the **Map|Layer Control...** menu to access the window shown in Figure 10.26. Then click on the **Add...** button in the Layers portion of the window. Choose the layer you want to add, in this case Query2, and click on **Add**. Finally use the **Display...** button to modify the symbols that are used to represent the Query2 database, so that you can distinguish the specified sites from the rest of the hazardous materials sites. The final map is shown in Figure 10.27.



**Figure 10.25** Viewing the results of the query



**Figure 10.26 Mapping the query results**



**Figure 10.27 Identification (by large triangles) of hazardous materials sites storing ammonia or chlorine**

A complete Fire Following Earthquake Model requires extensive input including the types and density of fuel, the number of fire fighting apparatus, the functionality of the water system, the occurrence of hazardous materials releases, and wind conditions to mention a few. To simplify the input, **HAZUS** limits the analysis to an estimate of the number of ignitions, an estimate of the size of the potential burned area, and estimates of exposed population and exposed inventory.

**Table 10.10 Induced Physical Damage Module Outputs - Fire Following Earthquake**

Component	Description of Output	Measure
Ignition	a) <b>HAZUS</b> determines the expected number of fire ignitions by census tract for the study region.	a) Number of ignitions
Burned Area	a) <b>HAZUS</b> determines the expected burned area by census tract for the study region.	a) Percentage of Burned Area
	b) Expected burned area is combined with population and economic value to estimate exposed population and inventory.	b) Exposed Population Exposed Value (\$)

The output from fire following earthquake module are presented in **HAZUS** in a table as shown in Figure 10.28. For each census tract in the study region the following quantities are displayed:


- Best estimates of the percent of the census tract that has been burned
- Standard deviation of the estimate of percent of burned area
- Number of ignitions in the census tract
- The population in the census tract that is exposed to fire (% burned area X total population in census tract)
- The value of inventory (in dollars) in the census tract fire exposed to fire (% burned area X total building value in census tract)

	Census Tract	Burnt Area	Sigma	Number Ignitions	Population Exposed	Value Exposed (thous. \$)
21	41005021700	7.06	0.6	0	352	18,270.7
22	41005021800	5.27	1.0	1	454	20,222.7
23	41005021900	5.91	1.0	0	163	8,973.4
24	41005022000	5.91	1.0	0	361	14,343.7
25	41005022101	2.42	1.0	0	157	5,691.2
26	41005022102	1.48	1.0	1	108	10,822.7
27	41005022201	0.00	0.0	0	0	0.0
28	41005022202	0.00	0.0	0	0	0.0
29	41005022300	7.38	0.4	1	501	19,213.8
30	41005022400	0.00	0.0	0	0	0.0
31	41005022500	2.31	0.3	1	159	7,023.2
32	41005022600	1.26	1.0	1	108	4,662.3
33	41005022701	1.57	1.0	1	116	8,808.5
34	41005022702	2.60	0.4	0	118	6,268.1
35	41005023200	0.00	0.0	0	0	0.0
36	41005023300	0.00	0.0	0	0	0.0
37	41051000100	5.11	1.0	1	284	17,232.4
38	41051000200	0.00	1.0	1	0	0.0
39	41051000301	0.00	0.0	0	0	0.0
40	41051000302	13.46	0.1	1	892	43,068.2
41	41051000401	0.00	0.0	0	0	0.0

**Figure 10.28 Output of fire following earthquake module**

Highlighting the column and then clicking on the Map button can map any of the columns in Figure 10.28. The “Burnt Area (%)” column has been mapped in

Figure 10.29. A summary report of the output of the Fire Following Earthquake module can also be printed to the screen or to a printer.



**Figure 10.29** Map of percent of each census tract burned

**HAZUS** provides information about the debris generated during the seismic event to enable users to prepare and to rapidly and efficiently manage debris removal and disposal. As shown in Table 10.11, two types of debris are identified (1) reinforced concrete and steel that requires special equipment to break it up before it can be transported, and (2) brick, wood and other debris that can be loaded directly onto trucks with bulldozers. For each census tract, **HAZUS** determines the amount of debris of each type that is generated.

**Table 10.11** Induced Physical Damage Module Outputs - Debris

Component	Description of Output	Measure
Brick, Wood & Others	a) <b>HAZUS</b> determines the expected amount of brick, wood, and other debris generated in each census tract of the study region.	a) Weight of Debris Generated
Reinforced Concrete & Steel	a) <b>HAZUS</b> determines the expected amount of reinforced concrete and steel debris generated in each census tract of the study region.	a) Weight of Debris Generated

In **HAZUS** debris results will appear as a table, as shown in Figure 10.30, that can be printed to the screen or the printer. In addition, you will be able to map by census tract the weight of generated debris using the **Map** button, as shown in Figure 10.31.


**Debris Analysis Results**

Table:

	Census Tract	Brick, Wood (1,000 tons)	RC & Steel (1,000 tons)	Total Weight(1,000 tons)
1	41067032900	12.13	23.96	36.08
2	41067033200	4.44	10.16	14.60
3	41067033100	4.23	7.83	12.06
4	41067033300	7.32	10.02	17.34
5	41067032500	13.73	37.94	51.67
6	41067032101	3.21	6.25	9.47
7	41067032402	3.83	9.40	13.23
8	41067032403	3.90	6.36	10.26
9	41067032404	3.23	3.27	6.49
10	41067032601	11.39	22.66	34.05
11	41067032602	9.35	18.18	27.53
12	41051003902	4.16	7.85	12.01
13	41051003502	5.68	14.05	19.72
14	41051003501	4.76	9.39	14.15
15	41051003801	2.55	4.60	7.15
16	41051003802	3.96	7.20	11.16
17	41051003803	2.16	2.90	5.06
18	41051003901	7.12	12.97	20.08
19	41067032000	9.19	29.72	38.91
20	41005022701	21.34	50.66	72.00
21	41067031901	22.77	34.19	56.96

Buttons: Close, Map, Print..

**Figure 10.30** Output of the debris module in thousands of tons per census tract



**Figure 10.31** Weight of generated debris (brick, wood and other) by census tract


**10.9 Direct Economic and Social Losses**

HAZUS provides information concerning the estimated number of displaced households and persons requiring temporary shelter to enable the design of programs to temporarily shelter victims.

**Table 10.11 Direct Economic and Social Losses Module Outputs - Shelter**

Component	Description of Output	Measure
Displaced Households	a) HAZUS determines the expected number of displaced households by census tract in the study region.	a) Number of Displaced Households
Temporary Shelter	a) HAZUS determines the expected number of people requiring temporary shelter by census tract in the study region.	a) Number of People Requiring Temporary Shelter

The total number of displaced households for each census tract of the study region is one output of the shelter module. The number of displaced households is used to estimate the short-term shelter needs. Short-term shelter needs are reported in the number of people needing public shelter. The results, as displayed in Figure 10.32, are retrieved using the **Results|Shelter** menu. As with all results, these can be thematically mapped by highlighting a column and clicking on the **Map** button.



**Figure 10.32 Output of shelter module**

The output of the casualty module is summarized in Table 10.12.

**Table 10.12 Direct Economic and Social Losses Module Outputs - Casualties**


Component	Description of Output	Measure
-----------	-----------------------	---------

Casualties	a) <b>HAZUS</b> determines the expected number of casualties for each casualty severity (treat/release, hospitalized, life-threatening, death) by census tract for the study region.	a) Number of casualties for each of the four severities
------------	--	---

For each census tract, the following results (use **Results|Casualties** menu shown in Figure 10.33) are provided at three times of day (2 AM, 2 PM and 5 PM) by occupancy type or by building type and on an annual basis for the same three time of the day.

- Residential casualties (severity 1, 2, 3 and 4)
- Commercial casualties (severity 1, 2, 3 and 4)
- Industrial casualties (severity 1, 2, 3 and 4)
- Commuting casualties (severity 1, 2, 3 and 4)
- Total casualties (severity 1, 2, 3 and 4)

As with any other output, highlighting the desired column and clicking on the Map button can plot results.



**Figure 10.34 Casualties result menu**

**Casualties Analysis Results**

Night time casualties (2 AM) | **Day time casualties (2 PM)** | Commute time casualties (5 PM)

Table: Day time casualties (at 2 PM)

	Census Tract	RES-Severity 1	RES-Severity 2	RES-Severity 3	RES-Severity 4	COM-Severity 1	
20	41005022701	1.8	0.3	0.01	0.01	25.7	▲
25	41005020800	1.0	0.1	0.00	0.00	13.9	▲
26	41005020900	1.2	0.1	0.00	0.00	2.0	▲
32	41005020200	1.0	0.1	0.00	0.00	4.0	▲
33	41005020100	0.8	0.1	0.00	0.00	3.5	▲
34	41005020301	0.8	0.1	0.00	0.00	2.3	▲
35	41005020302	0.1	0.0	0.00	0.00	1.1	▲
36	41005020401	0.1	0.0	0.00	0.00	0.1	▲
37	41005020402	4.8	0.7	0.02	0.02	5.0	▲
38	41005022702	1.5	0.2	0.00	0.00	7.5	▲
171	41005020501	0.1	0.0	0.00	0.00	0.1	▲
172	41005020502	0.7	0.1	0.00	0.00	1.2	▲
173	41005020600	0.2	0.0	0.00	0.00	0.2	▲
174	41005020700	0.1	0.0	0.00	0.00	0.1	▲
175	41005021700	0.5	0.0	0.00	0.00	0.7	▲
176	41005021900	0.1	0.0	0.00	0.00	0.6	▲
177	41005022000	0.2	0.0	0.00	0.00	0.4	▲
178	41005022400	0.2	0.0	0.00	0.00	1.5	▲

Close Map Print..

**Figure 10.34 Output of casualty module showing residential casualties at 2 PM**


**HAZUS** provides economic loss information to enable users to motivate policy-makers to consider cost-benefit implication of mitigation activities. All default data for direct economic loss estimates are provided in 1994 dollars. You will need to convert 1994 dollars to those that are valid when you run your study. Losses for lifelines are reported separately from losses for buildings.

**Table 10.13 Direct Economic and Social Losses Module Outputs -  
Direct Economic Loss - Buildings**


<b>Component</b>	<b>Description of Output</b>	<b>Measure</b>
Repair and Replacement Costs	a) HAZUS determines the expected dollar loss due to the repair and replacement of the general building stock by census tract for the study region.	a) Dollar Loss
Contents Damage	a) HAZUS determines the expected dollar loss due to contents damage by census tract for the study region.	a) Dollar Loss
Business Inventory Damage	a) HAZUS determines the expected dollar loss due to business inventory damage by census tract for the study region.	a) Dollar Loss
Relocation Costs	a) HAZUS determines the expected dollar loss due to business relocation by census tract for the study region.	a) Dollar Loss
Capital-related Income Loss	a) HAZUS determines the expected business income loss by census tract for the study region.	a) Dollar Loss
Wage Loss	a) HAZUS determines the expected wage loss by census tract for the study region.	a) Dollar Loss
Rental Loss	a) HAZUS determines the expected dollar loss due to the repair and replacement of buildings by census tract for the study region.	a) Dollar Loss

Building loss estimates can be viewed by clicking on the **Results|Buildings Economic Loss** menu. Building losses are summarized in terms of the seven General Occupancy classes (Residential, Commercial, Industrial, Agriculture, Religious, Government and Education), or in terms of the 28 Specific Occupancy Classes. As can be seen in Figure 10.35, the total direct economic losses for each census tract are reported. The total losses include structural and non-structural repair, contents loss, relocation costs, proprietor's income loss and rental loss.

Losses also can be reported by type. The types reported are structural and non-structural repair, total building costs (the sum of structural and non-structural), contents loss, relocation costs, proprietor's income loss and rental loss. These losses are reported by census tract for each of the seven general occupancy classes as shown in Figure 10.36.



**Figure 10.35 Total building losses reported by general occupancy class and census tract**



**Figure 10.36 Types of building losses reported by general occupancy class and census tract**

The total loss of each type for all economic sectors can be viewed using the window shown in Figure 10.37. This window differs from that shown in Figure 10.36 in that, for example, the total cost of structural damage as reported in Figure 10.37 is the sum of the contents damage for all of the seven general occupancies shown in Figure 10.36.

The screenshot shows a software window titled "General Building Stock Direct Economic Loss by Specific Occupancy". It has a tab labeled "Total" and a sub-tab "by Specific Occupancy". Below the tabs is a "Table:" label. The table contains the following data:

Census Tract	Cost Structural Damage (thous. \$)	Cost Non-struct. Damage (thous. \$)	Cost Building Damage (thous. \$)
41005020100	3,032	13,442	16,474
41005020200	4,398	25,419	29,817
41005020301	3,806	24,540	28,346
41005020302	628	3,837	4,465
41005020401	428	2,290	2,718
41005020402	9,682	37,608	47,290
41005020501	266	1,481	1,747
41005020502	2,773	14,083	16,856
41005020600	516	2,807	3,323
41005020700	257	1,442	1,699
41005020800	8,808	30,733	39,541
41005020900	2,950	13,367	16,317
41005021000	405	2,438	2,843
41005021100	527	2,862	3,389
41005021200	429	2,585	3,014
41005021300	4,105	17,028	21,133
41005021400	435	2,174	2,609
41005021500	1,521	5,223	6,744

At the bottom of the window are buttons for "Close", "Map", "Print", and "Help".

Figure 10.37 Types of building losses reported by census tract

The screenshot shows the same software window as Figure 10.37, but with the "Occupancy" dropdown menu set to "RES1". The table below shows the damage costs for that specific occupancy class across various census tracts:

Census Tract	Cost Structural Damage (thous. \$)	Cost Non-struct. Damage (thous. \$)	Cost Building Damage (thous. \$)
41067032900	4,719	19,283	24,002
41067033200	687	3,768	4,455
41067033100	1,867	10,234	12,101
41067033300	4,651	18,926	23,577
41067032500	4,257	18,251	22,508
41067032101	1,281	7,022	8,303
41067032402	1,724	9,403	11,127
41067032403	1,490	8,170	9,660
41067032404	2,366	12,966	15,332
41067032601	6,270	25,512	31,782
41067032602	4,875	21,781	26,656
41051003902	2,824	10,269	13,093
41051003502	2,655	9,198	11,853
41051003501	2,415	9,253	11,668
41051003801	1,025	4,658	5,683

At the bottom of the window are buttons for "Close", "Map", "Print..", and "Help".

Figure 10.38 Types of building losses reported by census tract and specific occupancy

Finally, losses can be reported for each of the 28 specific occupancy classes for each census tract as shown in Figure 10.38.

The loss estimates for lifeline systems are summarized in Table 10.14. These are accessed through the **Results|Lifelines Economic Loss** menu.

**Table 10.14 Direct Economic and Social Losses Module Outputs -  
Direct Economic Loss - Lifelines**

Component	Description of Output	Measure
Repair and Replacement Costs	a) The methodology determines the expected dollar loss due to the repair and replacement of lifelines components.	a) Dollar Loss

Figure 10.39 shows an example of a results window for transportation systems. Losses are reported for each component of the system, for example, in this window, losses are reported for each highway bridge. You can create similar reports for each type of component and each type of lifeline by clicking on the tabs at the top of Figure 10.39 and using the list box next to the label “Table Type”. The results in Figures 10.35 through 10.39 can be mapped by clicking on the **Map** button.

ID	Class	Loss (thous. \$)
837	HBR5	143
838	HBR5	143
839	HBR5	143
840	HBR5	332
841	HBR5	33
842	HBR5	33
843	HBR5	38
844	HBR5	19
845	HBR5	18
846	HBR5	18
847	HBR5	23
848	HBR5	126
849	HBR5	114
850	HBR5	318
851	HBR5	74
852	HBR5	117
853	HBR5	117

**Figure 10.39 Direct economic losses to lifeline components**

### 10.10 Indirect Economic Impacts


HAZUS provides information concerning the indirect economic effects of the scenario event to enable financial institutions and government planners to anticipate losses and develop programs to compensate for them. The indirect economic impact information also enables users to motivate policy-makers to consider cost-benefit implications of mitigation activities.

**Table 10.15 Indirect Economic Impacts Module Outputs**

Component	Description of Output	Measure
Economic Output	a) Indirect output loss as a percentage of original output	a) Percentage
Employment	a) Indirect employment loss as a percentage of original employment	a) Percentage
Income	a) Indirect income loss as a percentage of original income	a) Percentage

### 10.11 Summary Reports

The options to view summaries of the outputs of each of the **HAZUS** modules are: Inventory, Building Damage, Lifeline Damage, Induced Damage and Losses as shown in the Figure 10.40. You can pick the summary report from any of the windows below and click on the **View** button to generate the report. Sample summary reports of building damage by general occupancy and building stock exposure by building type are shown in Figures 10.41 and 10.42. Additional information in these reports can be viewed by scrolling to the right. Clicking on the print button shown in Figure 10.41 can print reports.



**Figure 10.40 Summary report selection window for inventory summary report**

HAZUS Summary Report

Zoom Print Next Previous First Last Close

### Building Damage By General Occupancy

Jun 10, 1997

	Square Footage (Thousand.sq.ft)	Damage State Probability (%)		
		None	Slight	Moderate
<b>Oregon</b>				
<b>Clackamas</b>				
Residential	105,783	58.45	25.30	13.13
Commercial	30,141	41.82	21.05	23.62
Industrial	10,203	41.08	18.68	25.24
Others	5,643	51.30	19.50	19.13
<b>Multnomah</b>				
Residential	347,484	36.08	29.34	24.12
Commercial	110,116	35.91	22.37	26.63
Industrial	34,985	35.42	20.08	27.13
Others	13,111	34.64	21.71	26.92
<b>Washington</b>				
Residential	154,936	35.25	33.86	23.70
Commercial	38,809	28.95	17.97	30.31
Industrial	19,374	29.99	19.24	30.37
Others	5,211	28.56	22.22	28.18

Figure 10.41 Sample summary report of building damage by general occupancy

HAZUS Summary Report

Zoom Print Next Previous First Last Close


### Building Stock Exposure by Building Type

Jun 10, 1997

	Wood	Steel	Concrete	Precast	Reinforced Masonry
<b>Oregon</b>					
Clackamas	8,168,531	316,320	92,946	165,690	1,254,428
Multnomah	20,750,794	5,415,895	3,471,397	935,656	4,210,298
Washington	11,410,140	1,474,376	183,989	978,791	1,264,859
<b>Total State</b>	<b>40,329,465</b>	<b>7,206,591</b>	<b>3,748,332</b>	<b>2,080,137</b>	<b>6,729,585</b>
<b>Total Study Region</b>	<b>40,329,465</b>	<b>7,206,591</b>	<b>3,748,332</b>	<b>2,080,137</b>	<b>6,729,585</b>

Figure 10.42 Sample summary report of building stock exposure by building type

The 20 page **Global Summary Report** is a comprehensive standardized summary report that provides inventory, hazard and analysis results related to the scenario event. Selecting the **Other** tab as shown in Figure 10.40 will access the window that contains the **Global Summary Report**.



**Figure 10.40** The Global Summary report option

The Global Summary Report is organized as follows:

1. **General Description of the Region**
2. **Building and Lifeline Inventory**
  - 2.A **Building Inventory**
  - 2.B **Critical Facility Inventory**
  - 2.C **Transportation and Utility Lifeline Inventory**
3. **Earthquake Scenario Parameters**
4. **Direct Earthquake Damage**
  - 4.A **Buildings Damage**
  - 4.B **Critical Facilities Damage**
  - 4.C **Transportation and Utility Lifeline Damage**
5. **Induced Earthquake Damage**
  - 5.A **Fire Following Earthquake**
  - 5.B **Debris Generation**
6. **Social Impact**
  - 6.A **Shelter Requirements**
  - 6.B **Casualties**
7. **Economic Loss**
  - 7.A **Building Losses**
  - 7.B **Transportation and Utility Lifeline Losses**
  - 7.C **Long-term Indirect Economic Impacts**

## 10.12 Ground Truthing the Results


The analysis results obtained from HAZUS are the best estimates given the current state-of-the-art earthquake engineering algorithms, but when a real earthquake event occurs, the damage observed on the ground *is* the absolute.

Through the ground-truthing feature, HAZUS allows the user to feed it the real observed data so that analysis results can get refined. For example, HAZUS uses the damage to say the medical care facilities to calculate their functionality, but if the damage values can be updated with real observed data, then HAZUS can use those new values to refine the functionality analysis for said medical care facilities.

To use the ground-truthing feature, follow the steps below:


1. Run an analysis including all of the modules
2. By default, ground-truthing is off. To find out the current setting, select the **Analysis** menu option as shown in Figure 10.44. The ground-truthing option will either show as **Ground Truthing Off** or **Ground Truthing On**. Also, when ground truthing is off, all of the results tables are non-editable (they show up in blue.)

The ground truthing menu option is a toggle, so if the option is off, selecting it will toggle the ground truthing to *on*.



**Figure 10.44. The Ground Truthing option**

3. Select the results table which you need to edit/ground truth
4. Right-click the table to invoke the data management pop-up menu. When ground truthing is on, the option **Edit results** becomes enabled and can be selected as shown in Figure below.



**Figure 10.45 Ground Truthing option**

5. Click on **Edit results** then all the result cells become editable (showing in black). Edit the appropriate values as needed. When done, click **Close** and say **yes** to the **Data table changed. Save to file?**

Essential Facilities Analysis Results

Medical Care | Emergency Response | Schools

Table type: Structural damage

Table:

	ID	Name	Occupancy	None	Slight	Modera
1	1	PROVIDENCE MILWAUKIE HOSPITAL	EFHM	0.18	0.19	0
2	2	WLLAMETTE FALLS HOSPITAL	EFHM	0.14	0.17	0
3	3	KAISER SUNNYSIDE MED CENTER	EFHM	0.11	0.15	0

Close Map Print...

Figure 10.46 Results table in edit mode

- Re-run the analysis on the dependant modules (or if in doubt, run all modules). HAZUS will use the entered values when needed. In the example above, if the value for “Slight” is updated for the hospital ID 2, then this value and only this value will be used. All the other values will be calculated by HAZUS as before.

Steps 3 through 6 can be repeated as many times as needed. ***The ground truthing mode stays in effect until it is turned off explicitly.*** This allows the refinement of the results as more observed data is fed into the HAZUS.

Note:

When the ground truthing option is turned off, all of the entered values are *discarded*.

